

INSTRUCTION SHEET

MICROSmart

FC6A Series Expansion I/O module

This sheet provides brief operating instructions of the MICROSmart programmable controller. For details, see the FC6A Series MICROSmart User's Manual.

Safety Precautions

- Special expertise is required to use the MICROSmart.
- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MICROSmart.
- Keep this instruction sheet where it can be accessed by the end user.
- All MICROSmart modules are manufactured under IDEC's rigorous quality control system, but users must add backup or failsafe provisions to control systems use the MICROSmart in applications where heavy damage or personal injury may be caused if the MICROSmart should fail.
- Install the MICROSmart according to the instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MICROSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC before using the MICROSmart.
- In this instruction sheet, safety precautions are categorized in order of importance from Warning and Caution:

WARNING

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

CAUTION

Caution notices are used where inattention might cause personal injury or damage to equipment.

WARNING

- Turn off the power to the MICROSmart before starting installation, removal, wiring, maintenance, or inspection on the MICROSmart. Failure to turn off the power may cause damage, electrical shocks or fire hazard.
- Emergency stop and interlocking circuits must be configured outside the MICROSmart. If such a circuit is configured inside the MICROSmart, failure of the MICROSmart may cause disorder of the control system, damage, or accidents.
- SUITABLE FOR USE IN CLASS 1, DIVISION 2, GROUPS A,B,C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.
- Cet appareil convient uniquement à l'emploi dans des zones dangereuses de classe 1, groupes A,B,C et D; ou dans des zones non dangereuses.
- WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.
- Avertissement: risque d'explosion. Ne pas débrancher l'appareil tant que le circuit est sous tension, ou à moins d'être certain que lieu d'utilisation soit exempt de concentrations inflammables.
- THIS EQUIPMENT IS AN OPEN -TYPE DEVICE MEANT TO BE INSTALLED IN AN ENCLOSURE SUITABLE FOR THE ENVIRONMENT THAT IS ONLY ACCESSIBLE WITH THE USE OF A TOOL OR KEY.
- Cet appareil doit être installé dans un boîtier qui est adapté à l'environnement d'utilisation et uniquement accessible avec un outil d'ouverture ou une clé.

CAUTION

- The MICROSmart is designed for installation in equipment. Do not install the MICROSmart outside of equipment.
- Install the MICROSmart in environments as described in the user's manual. If the MICROSmart is used in places where it is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, or excessive shocks it will result in electrical shocks, fire hazard, or malfunction.
- The environment rating for using the MICROSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MICROSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to the proper tightening torque of 0.28 N-m or 0.49 N-m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MICROSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MICROSmart to Europe.
- If relays or transistors in the MICROSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MICROSmart.
- Do not disassemble, repair, or modify MICROSmart modules.

1 TYPE


Input module
DC input : FC6A-N08B1, FC6A-N16B1, FC6A-N16B3, FC6A-N32B3
AC input : FC6A-N08A11
Output module
Relay : FC6A-R081, FC6A-R161
Transistor sink : FC6A-T08K1, FC6A-T16K1, FC6A-T16K3, FC6A-T32K3
Transistor protect Source : FC6A-T08P1, FC6A-T16P1, FC6A-T16P3, FC6A-T32P3
Mixed I/O module
FC6A-M08BR1, FC6A-M24BR1

Applicable model : FC6A Series MICROSmart CPU module

2 Specification


Operating Temperature: -10 to +55°C (no freezing),
Storage Temperature: -25 to +70°C (no freezing)
Relative/Storage Humidity: 10 to 95%RH (no condensation),
Altitude or Air Pressure: 1,013 to 795hPa (0 to 2,000 m) during operation
1,013 to 701hPa (0 to 3,000 m) during transport,
Vibration Resistance: 5 to 8.4 Hz half amplitude 3.5 mm, 8.4 to 150 Hz,
acceleration 9.8 m/s² (1 G), X, Y, Z directions, 2 hours,
Shock Resistance: 147 m/s² (15 G), 11 ms, X, Y, Z, 3 axes, 6 directions, 3 times each
Installation Location: Inside cabinet (indoor use)
Temperature Code: T4A (DC input module, Output Relay module, Mixed I/O module)
T5 (Input AC module)
T6 (Output Transistor sink module, Output Transistor protect Source module)
Maximum Surrounding Air Temperature: 55°C
*See the user's manual for more details on the product specifications.

3 Parts Description



- Module label
Indicates the module Type No. and specifications.
- LED Indicator
Turns on when a corresponding in/output is on.
- Terminal No.
Indicates terminal numbers.
- Cable Terminal/Connector
These terminals or connectors connect output devices, input devices or power.
- Expansion Connector
Connects to the CPU and other I/O modules.

4 Connecting Modules





- When connecting an input or output module, remove the expansion connector seal from the CPU module.
- Place the CPU module and Expansion I/O module side by side. Put the expansion connectors together for easy alignment.
- With the expansion connectors aligned correctly and the unlatch button in the down position, press the CPU module and Expansion I/O module together until the latches click to attach the modules together firmly. If the unlatch button is in the up position, push down the button to engage the latches.

CAUTION


When an expansion module is not connected next, don't peel off the protection sticker.

5 Mounting Modules

For details about mounting and removing modules, see the user's manual.
[Mounting on DIN Rail]
Use a 35-mm-wide DIN Rail and BNL6 mounting clips to secure the modules.



[Direct Mounting on Panel Surface]
Pull out the DIN Rail Hook on the back of the module and insert the direct mounting Hook (FC6A-PSP2PN05) into the slot. Attach the module to the mounting plate using the screw holes. Attach the module to the mounting plate using M4 tapping screws, as shown below, or make 5 to 6mm mounting holes and secure the module using M4 pan head screws. Always give sufficient consideration to operability, ease-of-maintenance, and environmental resistance when deciding on the mounting position.



FC6A-N08B1, FC6A-N16B1, FC6A-N08A11, FC6A-R081, FC6A-R161, FC6A-T08K1, FC6A-T08P1, FC6A-T16K1, FC6A-T16P1, FC6A-M08BR1

FC6A-N16B3, FC6A-T16K3, FC6A-T16P3

FC6A-N32B3, FC6A-T32K3, FC6A-T32P3


FC6A-M24BR1

All dimensions in mm.

CAUTION


For UL/cUL, Horizontal mounting only.

6 Dimensions




All dimensions in mm.

7 Wiring




FC6A-T16K3




Rated load : 24VDC / 0.1A

FC6A-T16P3




Rated load : 24VDC / 0.1A

FC6A-T32K3




Rated load : 24VDC / 0.1A




Rated load : 24VDC / 0.1A

FC6A-T32P3




Rated load : 24VDC / 0.1A



Rated load : 24VDC / 0.1A

FC6A-M08BR1




Rated load : 30VDC / 2A (RES. GEN)
240VAC / 2A (RES. GEN)
Max COM current : 7A

CAUTION

- Use a Class 2 or SELV power supply source when power supply voltage less than 30V DC is required to power the terminal.
- Use minimum 60°C wire copper conductor only.

FC6A-M24BR1



Rated load : 30VDC / 2A (RES. GEN)
240VAC / 2A (RES. GEN)
Max COM current : 7A

8 Applicable Cable / Recommended Ferrule

The recommended ferrule is made by Phoenix Contact. To crimp the ferrules shown below, use a special crimping tool. (CRIMPFOX6 (1212034))

FC6A-N16B1, FC6A-R161, FC6A-T16K1, FC6A-T16P1, FC6A-M24BR1:

Applied cable	Recommended ferrule
UL1007/UL2464 AWG24	AI 0,25-8 (3203037), AI 0,25-10 (3241128)
UL1007/UL2464 AWG22	AI 0,34-8 (3203066), AI 0,34-10 (3241129)
UL1007/UL2464 AWG20	AI 0,5-8 (3200014), AI 1,5-10 (3200195), AI-TWIN2x0,5-10 (3203309)
UL1015	AWG20 AI 0,5-8 GB (1208966), AI 0,5-10 GB (3203150)

FC6A-N08B1, FC6A-N08A11, FC6A-R081, FC6A-T08K1, FC6A-T08P1, FC6A-M08BR1:

Applied cable	Recommended ferrule
UL1007/UL2464 AWG24	AI 0,25-10 (3241128)
UL1007/UL2464 AWG22	AI 0,34-10 (3241129)
UL1007/UL2464 AWG20	AI 0,5-10 (3201275), AI-TWIN2x0,5-10 (3203309)
UL1007/UL2464 AWG18	AI 0,75-10 (3201288), AI-TWIN 2x0,75-10 (3200975), AI 1,5-10 (3200195)
UL1015	AWG20 AI 0,5-10 GB (3203150)
UL1015	AWG18 AI 1-10 (3200182)
UL1015	AWG16 AI 1,5-10 (3200195)

() indicates the Type No. of PHOENIX CONTACT GmbH & Co. KG

9 Recommended Screwdriver / Tightening Torque

To the terminal block, use the recommended screwdriver made by Phoenix Contact and tighten terminal screws tightening torque.

FC6A-N16B1, FC6A-R161, FC6A-T16K1, FC6A-T16P1, FC6A-M24BR1:
Screwdriver : SZS 0,4x2,5 (1205037) / Tighten torque : 0.28 N-m

FC6A-N08B1, FC6A-N08A11, FC6A-R081, FC6A-T08K1, FC6A-T08P1, FC6A-M08BR1:
Screwdriver : SZS 0,6x3,5 (1205053) / Tighten torque : 0.49 N-m

() indicates the Type No. of PHOENIX CONTACT GmbH & Co. KG

MICROSmart User's manual can be downloaded from <http://www.idec.com/FC6Amanuals>