




EN Operating instructions. . . . . page 1  
Translation of the original operating instructions

**Mounting**

All measurements in mm.

**Key**

- 1 Hexagonal key screw M6
- 2 Washer (included in delivery MZM 100-B1)
- 3 Actuator MZM 100-B1
- 4 Hexagonal key screw M6
- 5 Washer
- 6 Mounting angle (included in delivery)
- 7 Hexagonal key screw M6 x 40 to DIN 912 (included in delivery)
- 8 Washer (included in delivery MZM 100 / MZM 120)
- 9 Solenoid interlock MZM 100 / MZM 120



**K. A. Schmersal GmbH & Co. KG**  
Mödinghofe 30, D - 42279 Wuppertal  
Postfach 24 02 63, D - 42232 Wuppertal

Phone: +49 - (0)2 02 - 64 74 - 0  
Telefax: +49 - (0)2 02 - 64 74 - 1 00  
E-Mail: [info@schmersal.com](mailto:info@schmersal.com)  
Internet: <http://www.schmersal.com>

