Diffuse mode sensor

c(Ul

OBD1000-R100-2EP-IO-0,3M-V31

with fixed cable and 4-pin, M8 connector

Miniature design with versatile

Extended temperature range

High degree of protection IP69K

IO-link interface for service and

The R100 series miniature optical sensors

are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a

distance measurement device. As a result of

this design, the sensors are able to perform

practically all standard automation tasks.

US

IO-Link

CE

Features

•

٠

•

Model Number

Diffuse mode sensor

mounting options


-40°C ... 60°C

process data


Product information

OBD1000-R100-2EP-IO-0,3M-V31

Dimensions



Electrical connection




Pinout

to



Indicators/operating means



The entire series enables sensors communicate via IO-Link. The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor. The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

Pepperl+Fuchs Group www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



			1
Technical data			Accessorie
General specifications Detection range		2 1000 mm	IO-Link-Mas
Detection range min.		20 50 mm	IO-Link mast
Adjustment range		50 1000 mm	separate pov
Reference target		standard white, 100 mm x 100 mm	M12 plug for
Light source		LED	OMH-R10X-
Light type		modulated visible red light	Mounting bra
LED risk group labelling		exempt group	
Diameter of the light spot Angle of divergence		approx. 65 mm at a distance of 1000 mm 3.7 °	OMH-R10X-
Ambient light limit		5.7 ° EN 60947-5-2	Mounting bra
Functional safety related param	eters		OMH-R10X-
MTTF _d	01013	724 a	Mounting bra
Mission Time (T _M)		20 a	-
Diagnostic Coverage (DC)		0 %	OMH-R10X-
Indicators/operating means			Mounting bra
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	OMH-ML100 Mounting aid sheet 1.5 mn
Function indicator		LED yellow: constantly on - object detected constantly off - object not detected	OMH-ML100 Mounting aid
Control elements		Light-on/dark-on changeover switch	ø 10 14 mi
Control elements		Sensing range adjuster	V31-GM-2M
Electrical specifications		10 30 V DC	Female cord
Operating voltage Ripple	UB	max. 10 %	Female cord
No-load supply current	I ₀	< 25 mA at 24 V supply voltage	V31-WM-2M
Protection class	•0		Female cord
Interface			Other eviteble
Interface type		IO-Link (via C/Q = pin 4)	Other suitable www.pepperl-f
Transfer rate		COM 2 (38.4 kBaud)	www.pepperi-i
IO-Link Revision		1.1	
Min. cycle time		2.3 ms	
Process data witdh		Process data input 1 Bit Process data output 2 Bit	
SIO mode support		yes	
Device ID		0x110101 (1114369) A	
Compatible master port type Output		~	
Switching type		The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / light-on, PNP normally closed / dark-on, IO-Link /Q - Pin2: NPN normally closed / dark-on, PNP normally open / light-on	
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected	
Switching voltage		max. 30 V DC	
Switching current		max. 100 mA , resistive load	
Usage category		DC-12 and DC-13	
Voltage drop	Ud	≤ 1.5 V DC	
Switching frequency	f	1000 Hz	
Response time		0.5 ms	
Conformity Communication interface		IEC 61131-9	
Product standard		EN 60947-5-2	
Ambient conditions			
Ambient temperature		-40 60 °C (-40 140 °F) , fixed cable -25 60 °C (-13 140 °F) , movable cable not appropriate for conveyor chains	
Storage temperature		-40 70 °C (-40 158 °F)	
Mechanical specifications			
Housing width		11 mm	
Housing height		37.1 mm 21.5 mm	
Housing depth Degree of protection		21.5 mm IP67 / IP69 / IP69K	
Connection		fixed cable 300 mm with M8 x 1 male connector; 4-pin	
Material			
Housing		PC (Polycarbonate)	
Optical face		РММА	
Mass		approx. 10 g	
Cable length		0.3 m	

ies

ster02-USB ster, supply via USB port or ower supply, LED indicators, or sensor connection

-01 racket

-02 racket

-04 racket

(-10 racket

0-03 id for round steel ø 12 mm or ım ... 3 mm

0-031 id for round steel nm or sheet 1 mm ... 5 mm

M-PUR dset, M8, 4-pin, PUR cable

M-PUR dset, M8, 4-pin, PUR cable

le accessories can be found at -fuchs.com

Approvals and certificates

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





2


E87056, cULus Listed, class 2 power supply, type rating 1

UL approval

Curves/Diagrams








Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

Δ

